

BIG BIKE PARTS® INSTALLATION INSTRUCTIONS

PART NO. WINDSHIELD GARNISH

52-795

FOR HONDA GL1800

GOLDWING 2001-2010 & 2012

ITEMS REQUIRED: 10MM WRENCH

INSTALLATION:

1. RELEASE THE HEIGHT ADJUSTMENT LEVER (1A) (LEFT & RIGHT).
2. PULL BACK THE RUBBER COVER (1B) OVER LEFT & RIGHT MIRRORS.
3. USING 10MM WRENCH REMOVE THE BOLT (2A), WASHER (2B) AND RUBBER WASHER (2C) ON BOTH SIDES. BE CAREFUL NOT TO DROP ANY OF THE HARDWARE.

NOTE: THE MIRROR CAN BE TILTED FORWARD TO HELP GAIN ACCESS TO BOLT.

4. PULL THE OLD WINDSHIELD GARNISH STRAIGHT (2D) OUT TO RELEASE THE BOSSES (2E) FROM THE GROMMETS (2F).
5. INSTALL THE NEW WINDSHIELD GARNISH IN THE REVERSE OF REMOVAL.

