

PART NO. 52-822

BATTERY SIDE COVERSHONDA GOLDWING
2012-2013

TOOLS NEEDED: PHILLIPS SCREWDRIVER

NOTE: THREAD LOCK COMPOUND SHOULD BE USED ON ALL HARDWARE

PLEASE READ THROUGH AND UNDERSTAND THESE INSTRUCTIONS BEFORE BEGINNING.

INSTALLATION

1. STARTING ON THE LEFT SIDE OPEN THE LEFT SADDLEBAG LID.
2. CAREFULLY FROM THE BOTTOM PULL OUT THE SIDE COVER AND LAY IT FACE DOWN ON A CLEAN TOWEL.
3. USING A PHILLIPS SCREWDRIVER REMOVE THE THREE SCREWS HOLDING THE BLACK LOWER SIDE COVER TO THE PAINTED SIDE COVER.
4. TAKE THE NEW CHROME LOWER SIDE COVER AND CAREFULLY LINE UP THE HOLES IN THE PAINTED SIDE COVER WITH THE BOSSES IN THE NEW COVER. MAKE SURE THAT UPPER PANEL IS TIGHT TO THE BOSS BEFORE STARTING ANY SCREWS.
5. USING THE PHILLIPS SCREWDRIVER REINSTALL THE THREE SCREWS. BE VERY CAREFUL NOT TO OVER TIGHTEN THEM AND CRACK THE BOSSES.
6. INSTALL THE LEFT SIDE COVER BY SLIDING THE TOP UNDER THE SEAT AND THEN PUSHING THE MOUNTING STUDS INTO THE GROMMETS ONE AT A TIME.
7. REPEAT STEPS 1 THROUGH 6 ON RIGHT SIDE.