

# BIG BIKE PARTS®

## INSTALLATION INSTRUCTIONS

SADDLEBAG STAYS

FOR SPIRIT 1100C '99-05

PART NO. 53-125

TOOLS NEEDED: 5MM ALLEN WRENCH      12MM SOCKET      14MM SOCKET

1. USING 14MM SOCKET, REMOVE THE BOLT AT FRONT OF FENDER STRUT.
2. USING 12MM SOCKET, REMOVE BOLT AT REAR OF FENDER STRUT.
3. USING 10MM BOLT PROVIDED AT FRONT OF FENDER STRUT AND 8MM BOLT PROVIDED AT REAR OF FENDER STRUT, INSTALL THE SADDLEBAG STAY.
4. REPEAT STEPS 1 THROUGH 3 FOR OTHER SIDE.