

BIG BIKE PARTS® INSTALLATION INSTRUCTIONS

Front Caliper Covers
Part No. 53-428

Fits Honda
VT750 Aero

TOOLS NEEDED: 12MM WRENCH
5MM ALLEN WRENCH

1. USING A 12MM WRENCH REMOVE THE TWO HEX HEAD BOLTS FROM THE FORKS THAT ARE HOLDING THE CALIPER ON.
2. INSTALL THE NEW CALIPER COVER BY USING THE TWO SPACERS PROVIDED ON THE INSIDE OF THE NEW COVER AND USING THE TWO M8 X 1.25 X 50MM LONG ALLEN HEAD BOLTS PROVIDED.

NOTE: WE RECOMMEND USING LOCTITE ON ALL BOLTS.

Rely only on high-grade motorcycle brake parts offered on our virtual shelves.