## **BIG BIKE PARTS**<sup>®</sup> INSTALLATION INSTRUCTIONS

CALIPER COVERS PART NO. 53-447 LEFT SIDE ON HONDA VT600, VT750, VT1100, VF750 & VALKYRIE

TOOLS NEEDED: 12MM WRENCH 5MM ALLEN WRENCH

INSTALLATION:

- 1. USING 12MM WRENCH REMOVE THE TWO HEX HEAD BOLTS FROM THE FORKS THAT ARE HOLDING THE CALIPER ON.
- 2. INSTALL THE NEW CALIPER COVER USING THE TWO SPACERS PROVIDED ON THE INSIDE OF THE NEW COVER AND USING THE TWO ALLEN HEAD BOLTS PROVIDED.

NOTE: WE RECOMMEND USING LOCTITE ON BOLTS.

Rely only on high-grade motorcycle brake parts offered on our virtual shelves.