

# **BIG BIKE PARTS®** **INSTALLATION INSTRUCTIONS**

**PART NO. 55-107**      **CALIPER COVERS**  
**HONDA VTX 1800**

**TOOLS:** 12MM WRENCH    8MM ALLEN WRENCH

1. USING 12MM WRENCH REMOVE THE TWO HEX HEAD BOLTS FROM THE FORKS THAT HOLD THE CALIPER ON.
2. INSTALL THE NEW CALIPER COVER USING THE TWO SPACERS PROVIDED ON THE INSIDE OF THE NEW COVER USING THE TWO ALLEN HEAD BOLTS PROVIDED.

**NOTE: WE RECOMMEND USING LOCTITE ON BOLTS.**