

BIG BIKE PARTS®

INSTALLATION INSTRUCTIONS

Rear Caliper Cover

Fits Honda VTX 1800

Part No. 55-121

TOOLS NEEDED: 14MM SOCKET WRENCH
2.5MM ALLEN WRENCH

INSTALLATION:

1. USING 14MM SOCKET WRENCH REMOVE THE BOLT ON THE FAR RIGHT SIDE OF THE CALIPER. THE BOLT WILL PULL OUT ONCE UNSCREWED.
2. STICK THE FOAM TAPE ONTO THE FACE OF THE CALIPER.
3. POSITION THE REAR CALIPER COVER IN PLACE AND PUT THE BOLT BACK INTO CALIPER THROUGH THE HOLE IN THE CALIPER COVER.
4. PLACE THE "J" HOOK ON THE HOSE ON THE LEFT SIDE OF CALIPER AND SCREW IT DOWN WITH THE M3 X .40 X 8MM LONG SCREW PROVIDED.