

BIG BIKE PARTS® INSTALLATION INSTRUCTIONS

DRIVE SHAFT BOLT TRIM

PART NO. 55-134

TOOLS NEEDED: 3MM ALLEN WRENCH

1. PUT M6 X 1.00 X 12MM LONG SOCKET HEAD SET SCREWS INTO PART.
2. ALIGN CUTOUTS WITH THE BOLTS ON THE DRIVE SHAFT HOUSING.
3. STARTING WITH THE BOTTOM SET SCREW, TIGHTEN UNTIL SNUG. THEN TIGHTEN THE TOP SET SCREW UNTIL SNUG.

NOTE: WE RECOMMEND USING LOC-TITE ON ALL SCREWS