

BIG BIKE PARTS[®] INSTALLATION INSTRUCTIONS

TRIPLE TREE ACCENT COVER

PART NO'S.	53-420
	53-423
	55-131
	55-315
	82-217

TOOLS REQUIRED: WRENCH

NOTE: IT IS RECOMMENDED TO USE TWO PEOPLE WHEN INSTALLING THIS PART AND TO USE A TOWEL OR MECHANICS APRON TO PROTECT THE TANK

INSTALLATION:

1. USING A WRENCH REMOVE THE TWO MOUNTING NUTS THAT HOLD THE HANDLEBAR RISERS TO THE TREE.
2. PEEL OFF BACKING AND PLACE THE DOUBLE SIDED TAPE PROVIDED INSIDE THE TRIPLE TREE ACCENT COVER.
3. PULL THE HANDLEBARS UP AND PUT THE TRIPLE ACCENT COVER INTO PLACE.
4. REINSTALL THE HANDLEBAR RISERS.