

BIG BIKE PARTS® INSTALLATION INSTRUCTIONS

PART NO. 55-322

SISSY BAR RACK

TOOLS NEEDED: 13MM WRENCH
4MM ALLEN WRENCH

6MM ALLEN WRENCH
THREAD LOCKER

5MM ALLEN WRENCH

WE RECOMMEND USING A SMALL AMOUNT OF THREAD LOCKER ON ALL HARDWARE INSTALLED.

1. ATTACH THE TWO BRACKETS (A) TO THE RACK (B) USING THE FOUR M6 – 1.0 COUNTERSUNK CAP SCREWS (C). THE TOP OF THE BRACKET SHOULD MATE UP AGAINST THE OPPOSITE FACE THAT THE COUNTERSINKS ARE ON, AND THE TOP BENT TABS ON THE BRACKETS SHOULD FACE TO THE OUTSIDE OF THE RACK.
2. BACK OUT THE TWO BOLTS HOLDING THE BACKREST BRACKETS TO YOUR BIKE ABOUT HALFWAY.
3. IF YOU HAVE PREVIOUSLY INSTALLED THE BACK REST BAR, REMOVE THE FOUR M8 – 1.25 X 30MM LONG BOLTS AND ACORN NUTS AND REPLACE THEM WITH THE LONGER 35MM LONG M8 BOLT SUPPLIED WITH THE RACK.
4. SLIDE THE RACK INTO PLACE MAKING SURE THE BRACKETS GO ON THE INSIDE OF THE SISSY BAR AND PUSH THE FOUR BOLTS THROUGH THE RACK BRACKETS AND TIGHTEN DOWN WITH THE PREVIOUSLY REMOVED ACORN NUTS.
5. TIGHTEN DOWN THE BOLTS LOOSENEED UP IN STEP #2.

