

TOOLS NEEDED: CLEAN CLOTH MILD SOLVENT OR CLEANER

PLEASE READ THROUGH AND UNDERSTAND THESE INSTRUCTIONS BEFORE BEGINNING.

THE MASTER CYLINDER CLAMP COVER IS DESIGNED TO FIT OVER THE EXISTING OEM MASTER CYLINDER MOUNTING CLAMP. IF YOU HAVE OTHER ACCESSORIES MOUNTED TO THE HANDLEBARS NEAR THE MASTER CYLINDER YOU MAY NEED TO RELOCATE THEM TO INSTALL THE MASTER CYLINDER CLAMP COVER. IT IS IMPORTANT THAT THE INSTALLATION INSTRUCTIONS ARE FOLLOWED CORRECTLY OR AN IMPROPER FIT MAY RESULT.

INSTALLATION:

1. PARK THE MOTORCYCLE ON LEVEL GROUND AND MAKE CERTAIN THAT IT IS IN A STABLE POSITION.
2. CLEAN THE MASTER CYLINDER MOUNTING CLAMP WITH A CLEAN, LINT FREE CLOTH AND A MILD SOLVENT OR CLEANER SUCH AS RUBBING ALCOHOL.
3. TEST FIT THE CLAMP COVER. DO NOT REMOVE THE BACKING FROM THE MOUNTING TAPE ON THE INSIDE OF THE COVER YET. MAKE CERTAIN THE COVER DOES NOT INTERFERE WITH ANY CONTROLS OR ACCESSORIES. YOU MAY NEED TO ADJUST THE LOCATION OF THE MASTER CYLINDER OR ACCESSORIES TO PROVIDE SUFFICIENT CLEARANCE.

NOTE: IF YOU ARE ALSO INSTALLING A MASTER CYLINDER COVER (55-356 OR 63-216) TEST FIT THE CLAMP COVER WITH THE MASTER CYLINDER COVER TO ENSURE THE ALIGNMENT IS CORRECT.

4. REMOVE THE BACKING FROM THE MOUNTING TAPE ON THE INSIDE OF THE CLAMP COVER. PLACE IT OVER THE CLAMP AND ALIGN IT. WHEN YOU ARE SATISFIED WITH THE LOCATION OF THE COVER PRESS IT FIRMLY INTO PLACE SO THE MOUNTING TAPE ADHERES FULLY TO THE SURFACES OF THE CLAMP. THE TAPE SHOULD BE ALLOWED TO SET FOR 72 HOURS BEFORE WASHING OR EXPOSURE TO WATER.