

BIG BIKE PARTS® INSTALLATION INSTRUCTIONS

PART NO. FRAME COVER
63-211 YAMAHA V-STAR 950

TOOLS NEEDED: RUBBING ALCOHOL, SHOP TOWEL

HARDWARE INCLUDED: NONE

INSTALLATION INSTRUCTIONS:

1. WITH RUBBING ALCOHOL AND THE SHOP TOWEL, CLEAN THE AREA FOR THE LEFT SIDE FRAME AND ALLOW AREA TO DRY.
2. PEEL THE BACKING FROM THE DOUBLE SIDED TAPE (C) FROM THE LEFT SIDE FRAME COVER (A).
3. PLACE THE LEFT SIDE FRAME COVER (A) IN PLACE AND PRESS FIRMLY TO INSURE GOOD ADHESION BETWEEN THE TAPE AND THE BIKE FRAME.
4. REPEAT STEP #1 THROUGH STEP #3 FOR THE RIGHT SIDE FRAME COVER (B).

