BIG BIKE PARTS®

INSTALLATION INSTRUCTIONS

CALIPER COVERS PART NO. 63-605

FOR YAMAHA XVS 1100 V-STAR CLASSIC

TOOLS NEEDED: 12MM WRENCH

5 MM WRENCH

INSTALLATION:

- USING THE 12MM WRENCH REMOVE THE TWO HEX HEAD BOLTS FROM THE FORKS THAT ARE HOLDING THE CALIPER ON.
- INSTALL THE NEW CALIPER COVER USING THE TWO SPACERS PROVIDED ON THE INSIDE OF THE NEW COVER AND USING THE TWO ALLEN HEAD BOLTS PROVIDED.

NOTE: WE RECOMMEND USING LOCTITE ON BOLTS