

# BIG BIKE PARTS® INSTALLATION INSTRUCTIONS

PART NO. 71-126

STEPPED FRONT CALIPER COVER

KAWASAKI VN2000

TOOLS NEEDED: 12MM WRENCH    5MM ALLEN WRENCH

1. WITH A 12MM WRENCH, REMOVE BOTH HEX HEAD FLANGE SCREWS WHICH ATTACH THE RIGHT BRAKE CALIPER TO THE MOUNTING BRACKET.
2. INSERT ONE M8 BUTTON SOCKET HEAD CAP SCREW THRU THE TOP HOLE IN THE CALIPER COVER, PLACING ONE SPACER OVER THE SCREW ON THE BACKSIDE OF THE COVER.
3. PLACE STEPPED RIGHT FRONT CALIPER COVER OVER THE BRAKE CALIPER, ALIGNING THE M8 SCREW WITH THE TOP HOLES IN THE MOUNTING BRACKET AND CALIPER, THEN HAND THREAD THE SCREW INTO CALIPER ENOUGH SO IT WON'T FALL OUT.
4. PLACE THE OTHER SPACER BEHIND THE BOTTOM CALIPER COVER HOLE, INSTALL THE OTHER PROVIDED M8 BUTTON SOCKET HEAD CAP SCREW THRU THE HOLE, ALIGNING THE BOLT WITH MOUNTING BRACKET AND CALIPER, THEN START THE SCREW BY HAND.
5. TIGHTEN THE BOLTS DOWN TO MANUFACTURER SPECIFICATIONS WITH A 5MM ALLEN WRENCH