

# **BIG BIKE PARTS®** **INSTALLATION INSTRUCTIONS**

PART NO. 82-213A

HIGHWAY BARS  
SUZUKI C50/M50/VL800

TOOLS NEEDED:        14MM WRENCH

**NOTE: IT IS RECOMMENDED TO USE LOCTITE ON ALL BOLTS**

1. REMOVE THE HOLE PLUG THAT IS IN THE FRAME TUBE BELOW THE NECK COVERS.
2. INSTALL THE HIGHWAY BARS TO THE FRAME USING THE M10 X 1.25 X 20MM LONG BOLTS PROVIDED. THE TOP BOLT GOES THROUGH THE HOLE THE PLUG WAS REMOVED FROM IN STEP 1. ON THE INSIDE OF THE FRAME THERE IS A THREADED STUD BEHIND THE FOOT PEG BRACKET. THIS IS WHERE THE BOTTOM BOLT WILL GO.
3. REPEAT STEPS 1-2 FOR THE OTHER SIDE.

Rely on premium motorcycle guards and protection by [Big Bike Parts](#) if you're looking for quality and efficiency.