

5013-KTM/5300-10 5301-00/5301-10 KICKSTAND INSTALLATION

00-04 KTM 250-525 SX/MXC/EXC

05-07 KTM 250-525 MXC/EXC/XC/XC-W

05-06 KTM 250-450 SX/SXF

5013-KTM/5300-10

● 00-04 KTM 250-525 SX/MXC/EXC



2004 KTM 450SX Kickstand Installed

1. Remove the 8mm lower chain guide bolt & nut.
2. Remove the lower rear sub-frame bolt.
3. Attach mounting bracket to frame as shown to right using the M8 bolts provided. (Use thread locking compound on the pivot bolt to ensure it does not back out.)
4. Hang spring as shown.

Replacement Kickstand Arm Kits for KTM:

KTM EXC/MXC (Stand and 8mm Bolt Only) 98-01
5003-KTM

KTM EXC/MXC (Stand and 8mm Bolt Only) 02-07
5003-KTM-A

Remove stock kickstand. Install Trail Tech kickstand using stock mounting points, spring and the included 8mm pivot bolt. Use thread locking compound on the pivot bolt to ensure it does not back out.

5301-00/5301-10

● 05-07 KTM 250-525 MXC/EXC/XC/XC-W

● 05-06 KTM 250-450 SX/SXF



1. Remove the 8mm lower chain guide bolt & nut.
2. Remove the lower rear sub-frame bolt.
3. Attach mounting bracket to frame as shown to right using the M8 bolts provided. (Use thread locking compound on the pivot bolt to ensure it does not back out.)
4. Hang spring as shown.

IMPORTANT: WEAR EYE PROTECTION WHEN HANGING SPRINGS!

Note: After every ride it is important to check your kickstand thoroughly for the following:

- Loose or damaged bolts
- Bent or damaged kickstand leg or bracket
- Damaged spring

Damaged or broken parts can result in serious injury! If any part of your stand has become damaged do not ride the machine! Contact a factory trained technician or Trail Tech directly for service or repairs.