



**INSTALLATION INSTRUCTIONS FOR
PART 1602S
GL1500 SMOKE AIR DAMPNER**

NOTE: Hooks are long to accommodate chrome grills. Cut 1/4" off if you do not have chrome grills. While installing, the lower air vents must be open. Check your engine temperature. Not for use in warm weather.

