



INSTALLATION INSTRUCTIONS FOR PART 18260 GL1800 FRONT FENDER FILLERS

1. Clean inside fender.
2. Remove paper and heat with hair dryer.
3. Position properly and press firmly.



View [other motorcycle chrome trim & custom accessories](#) made by [V&P](#) on our website.