



## Installation instructions

Akrapovič Exhaust System  
**Slip-On**  
for the  
**Yamaha YZF-R1**

Congratulations on purchasing the Akrapovič exhaust system.

**Please read this entire installation manual carefully prior to installing and using the Akrapovič exhaust system.**

Akrapovič exhaust system should only be installed by persons skilled in motorcycle exhaust system installation and performance. The instructions provided in this manual should be followed to ensure proper installation and safe use of the Akrapovič exhaust system. Akrapovič and/or its partners shall not be held liable for any damage or personal injury (including direct, indirect, or consequential damage) sustained as a result of improper installation of the Akrapovič exhaust system or its use and maintenance contrary to the instructions and warnings contained herein.

If you have any questions regarding the installation and/or proper use of the Akrapovič exhaust system or this

## **GENERAL INFORMATION**

Your safety is our number one priority. Please ride your motorcycle responsibly, safely and always obey local traffic rules.

All statements made with regard to the exhaust system's compliance are made in respect of the exhaust system "as is". Any modifications of the Akrapovič exhaust system or its improper installation, use or maintenance that is not in accordance with this Installation manual, may result in severe damage to the exhaust system and/ or engine, as well as personal injury, and may affect the exhaust system's compliance with the legal requirements, such as exhaust system's air and/ or noise emissions (as an example, the motorcycle may not be suitable for use on public roads any longer), as well as warranty coverage.

The exhaust system may only be used in accordance with relevant laws and regulations, including state and federal, where applicable.

Damage caused by improper installation, use and maintenance of the Akrapovič exhaust system is not covered by the Akrapovič warranty. Please refer to the enclosed warranty with regard to the terms of our warranty.

Technical specifications of Akrapovič exhaust systems and related products are subject to change without notice.

## **COPYRIGHT AND OTHER RIGHTS NOTICE**

The Akrapovič trademark, including corporate logos and emblems, are subject to copyright as well as trademark rights of Akrapovič, its licensors, or third persons authorizing Akrapovič to use them.


Any reproduction, technical or other manipulation, translation, or other use of the copyright and/or trademark rights contained herein is prohibited without the explicit prior written consent of Akrapovič. The same especially applies to the entire contents of this manual and/or any of its parts, including but not limited to technical specifications, instructions, graphs, photographs, and so on included in this manual.

The shape of the exhaust system is protected under a registered Community Design No. RCD 002747329-0001.

## SAFETY AND COMPLIANCE WARNING, PLEASE READ CAREFULLY

**BEFORE REMOVING THE STOCK EXHAUST SYSTEM AND BEGINNING THE INSTALLATION OF YOUR NEW AKRAPOVIČ EXHAUST, PLEASE MAKE SURE THAT ALL ITEMS LISTED BELOW ARE VERIFIED:**

- THIS MANUAL IS SPECIFIC TO THE MOTORCYCLE INDICATED ON THE COVER PAGE, FOR WHICH IT IS DESIGNED. INSTALLATION PROCEDURES VARY DEPENDING ON THE TYPE OF MOTORCYCLE. PLEASE VERIFY THAT THE AKRAPOVIČ **EXHAUST SYSTEM AND THIS INSTALLATION MANUAL CORRESPOND TO THE TYPE OF YOUR MOTORCYCLE.**
- THE EXHAUST SYSTEM CAN GET EXTREMELY HOT DURING AND AFTER IT IS USED. MAKE SURE NOT TO TOUCH THE EXHAUST SYSTEM UNTIL IT IS COMPLETELY COOL. **ALLOW THE EXHAUST AND ENGINE TO COOL DOWN BEFORE BEGINNING INSTALLATION.**
- MAKE SURE THE MOTORCYCLE IS **SECURELY POSITIONED TO PREVENT TIPPING OVER** AND DAMAGE TO YOURSELF AND OTHERS, OR THE MOTORCYCLE.
- PLEASE CHECK THE PARTS YOU RECEIVED AGAINST THE PARTS LIST AVAILABLE ON OUR WEBSITE. MAKE SURE THAT YOU HAVE **ALL THE PARTS NECESSARY FOR THE INSTALLATION** OF YOUR NEW AKRAPOVIČ EXHAUST SYSTEM. IF ANY OF THE PARTS IS MISSING, PLEASE DO NOT PROCEED WITH UNINSTALLING YOUR STOCK EXHAUST SYSTEM/ INSTALLING THE AKRAPOVIČ EXHAUST SYSTEM AND CONTACT THE RETAILER WHERE YOU PURCHASED THE AKRAPOVIČ EXHAUST SYSTEM.
- ALWAYS **SECURE YOUR MOTORCYCLE'S GROUND CLEARANCE.** FOR ADVANCED USERS, WE RECOMMEND YOU CHECK THE MOTORCYCLE SPRING PRELOAD SETTINGS TO OPTIMIZE GROUND CLEARANCE WHERE POSSIBLE.
- EVERY EXHAUST SYSTEM MUFFLER HAS ITS UNIQUE SERIAL NUMBER, WHICH IDENTIFIES THE AUTHENTICITY OF THE PRODUCT. YOU CAN FIND THE SERIAL NUMBER ON THE MUFFLER'S INLET PIPE. PLEASE REFER TO THE PICTURE BELOW. PLEASE VERIFY THAT YOUR EXHAUST SYSTEM IS AN ORIGINAL AKRAPOVIČ PRODUCT. IF YOU HAVE ANY DOUBTS, PLEASE CONTACT THE RESELLER WHERE YOU PURCHASED THE EXHAUST SYSTEM OR AKRAPOVIČ PARTNERS. THIS MANUAL, ANY CERTIFICATES AND AKRAPOVIČ WARRANTY APPLY TO ORIGINAL PRODUCTS ONLY.



SERIAL NUMBER POSITION

## NOISE AND EMISSION WARNINGS

### General warning

Because of the world-wide distribution of Akrapovič d.d. products, neither Akrapovič d.d. nor any of its subsidiaries make any representation that the exhaust system complies with the air and/or noise emissions laws, or labeling laws, of any jurisdiction. The purchasers are entirely responsible for informing themselves of the applicable laws where the products are to be used and to comply with those law.

Although legal compliance of Akrapovič products in a specific country should be determined by the user, you can find some basic guidance on compliance of your Akrapovič exhaust system with various legal requirements on the product-related part of our website. For EC and ECE type approvals, please refer to the certificate enclosed to your product.

### USA WARNING

Various U.S. states and the U.S. federal government have individual laws regulating the use of aftermarket exhaust parts and systems, especially as those parts and systems modify, remove, or replace original equipment catalysts. Please consult the appropriate laws in your area before installing any aftermarket part or system on your vehicle to ensure compliance with all applicable laws. Neither Akrapovic d.d. nor any of their subsidiaries or the sellers of the parts or systems make any representation that any of their parts or systems comply with any such laws.

### CALIFORNIA WARNING

California laws prohibit the use of any aftermarket exhaust part or system that modifies, removes or replaces original equipment catalysts unless the California Air Resources Board has issued an Executive Order regarding such part or system or unless the part or system is exempted by being used only on racing vehicles on closed courses. Neither Akrapovic d.d. nor any of their subsidiaries make any representation that any of their parts or systems has received such an Executive Order or that any of their parts or systems conform with the racing vehicles exemption. The purchasers are entirely responsible for informing themselves of applicable California laws and to comply with those laws.

### GENERAL NOTE

Photographs and other illustrations in this manual are symbolic and are intended to help represent individual steps for proper installation and use, as well as for a general overview. The actual component parts of the Akrapovič exhaust system may not entirely correspond to the photographs and other illustrations.

### SYMBOLS

The following symbols are used throughout these installation instructions:



**TOOLS AND PROTECTIVE EQUIPMENT REQUIRED**



**TIGHTENING TORQUE**



**LUBRICATION**



**HAND TIGHTEN**



**INSTALLATION TIP**



**CAUTION OR IMPORTANT**

#### USE BOLT SEALANT



Apply 3 to 4 small drops of bolt sealant onto the cleaned and degreased threads before tightening the bolts.

**WARNING! Avoid contact with skin, eyes and mucous membranes. Do not inhale fumes. Keep out of reach of children.**

#### USE ANTI-SEIZE LEAD-FREE COPPER PASTE (black tube)



Provides trouble-free and long-lasting protection against seizing, corrosion and rusting of bolts, threaded ends, nuts, joints, etc. Also protects against vibration, wear and impact.

**WARNING! Avoid eye contact. Keep out of reach of children.**


#### USE ANTI-SEIZING GREASE (white tube)



Prevents seizing, corrosion and excessive wear between the titanium components of your exhaust system.

**WARNING! Avoid eye contact. Keep out of reach of children.**

## Tools & equipment



- T-handle 8mm wrench
- T-handle 12mm wrench
- T-handle 12mm swiveling wrench
- T-handle 4mm three hexagon key wrench
- T-handle 5mm three hexagon key wrench
- T-handle 6mm three hexagon key wrench
- Small cross head screwdriver
- Combination 14mm wrench

## PARTS LIST

The following parts should be found in the box:

- Installation Manual
- Homologation certificate/ compliance documents if applicable
- Warranty
- Fitting material
- Muffler and pipes

## REMOVAL OF STOCK EXHAUST SYSTEM:

The process of uninstalling the original exhaust system may vary depending on the existing exhaust system. Please follow the original exhaust system manufacturer's instructions for uninstalling the original exhaust system.

If you for any reason decide otherwise, please note that any information provided in this respect herein should be considered as general information provided for your convenience only. Akrapovič shall not assume any liability or responsibility with regard to uninstalling your existing exhaust system, warranty coverage of such exhaust system or vehicle or their further fitness for use.

**In case your Akrapovič exhaust system may not be used on certain roads or under certain conditions, please keep the stock or other exhaust system that you can use in such circumstances legally.**

## REMOVAL OF STOCK EXHAUST SYSTEM:

1. Put the motorcycle on a side stand, we recommend a racing stand. Make sure, that surface is solid and flat.
2. Unlock and remove the rear passenger's seat (F 01).



3. Unscrew and remove the driver's seat (F 02).





4. Unscrew the bolts and remove the original mufflers heat shields (F 03).



5. Unscrew the bolt and undo the plastic fasteners from the seat cowling (F 04, 05, 06, 07, 08).





F 05



F 06





F 07



F 08

6. Unhook the cable for locking/unlocking the seat and remove the seat cowling (F 09).



7. Unscrew and remove the original link pipe heat shields and unhook the brake line (F 10, 11).





8. Unscrew the bolt from the link pipe metal clamp (F 12), the bolt from the muffler hanging bracket and remove the muffler.






9. Perform the process on both sides of the motorcycle (F 13, 14).



10. For optional Y link pipe only: disconnect the stop switch electrical lead (F 15).



11. Unscrew the bolts from the rider's footrest bracket and rear brake stop switch. (F 16, 17).

**!** IMPORTANT: do not disconnect the brake fluid tube!







F 17

12. Unscrew and remove the lambda sensor (F 18).

! **IMPORTANT:** make sure not to damage lambda sensor's electrical lead!



F 18



13. Unscrew and remove the metal clamp of the stock link pipe/header assembly joint (F 19).



14. Unscrew the bolt from the original link pipe metal bracket and remove the original link pipe and stock gasket metal collar (F 20, 21, 22).





F 21




F 22

## INSTALLATION OF THE AKRAPOVIC SLIP-ON EXHAUST SYSTEM:

1. For optional Y link pipe only: reposition the original link pipe bracket to the Akrapovic optional link pipe using stock bolt and spacer; tighten the bolt to a specified torque (F 23, 24).

**CAUTION:** be careful not to injure yourself or damage any part of the motorcycle during this procedure!



2. Reposition the original aluminium heat shield to the Akrapovic optional link pipe using original spacers and Akrapovic 12mm bolts; tighten the bolts to a specified torque (F 25, 26, 27).




F 25



F 26






3. Coat the bolt and interior of metal clamp with Akrapovic anti-seize lead-free copper paste (black tube) and correctly install the metal clamp onto the link pipe (F 28).



4. For optional Y link pipe only: redirect the lambda electrical lead (as shown in figure) to enable correct installation of the sensor into Akrapovic link pipe (F 29).
- ! **IMPORTANT:** make sure that electrical lead of the lambda sensor does not touch hot or moving parts of the motorcycle!




5. Tighten the lambda sensor; make sure not to damage the electrical lead during this process (F 30).
- ! **IMPORTANT:** grease only the threads of the lambda sensor with Akrapovic anti-seize lead-free copper paste (black tube)!






6. For optional Y link pipe only: slide the optional link pipe onto the original header tube and tighten the link pipe stock bracket using stock bolt to a specified torque (**F 31, 32, 33**). Tighten the metal clamp (Tightening torque: 9,8NM / 7ftlb). Make sure the link pipe is not touching the frame and other parts.





7. For optional Y link pipe only: replace the rider's footrest bracket, brake line and reconnect the rear brake stop switch in the reverse order from the order in which they were removed (F 34, 35).







8. Coat the bolts and interior of metal clamps with Akrapovic anti-seize lead-free copper paste (black tube) and correctly install the metal clamps onto the link pipes (**F 36**).



9. Correctly position and install the Akrapovic carbon-fiber heat shield onto the link pipes; make sure the heat / distance washers are correctly installed (F 37, 38, 39).



F 37



F 38



F 39

10. Correctly position the carbon-fiber clamps and slide them onto the mufflers as seen in the figures (F 40, 41).

**!** **IMPORTANT:** open the clamp slightly wider than the diameter of the outer sleeve of the muffler – do not scrape it along the muffler outer sleeve!



F 40



F 41

11. Remove the stock metal collar and insert the additional Akrapovic aluminium muffler bracket to the chassis hanging bracket – use the bolt and washer supplied in the Akrapovic kit. Do not fully tighten. Make sure the additional parts from the Akrapovic kit are correctly installed (F 42, 43, 44). Perform the process on both sides of the motorcycle.



F 42





F 43



F 44

12. Position the mufflers correctly and slide them onto the outlet side of the link pipes. Hand tighten the muffler clamps to Akrapovic aluminium muffler bracket using Akrapovic bolts and washers (fi 15mm). Align the mufflers in respect to the motorcycle and tighten the bolts of the Akrapovic muffler clamps, muffler brackets and metal clamps (F 45, 46, 47, 48, 49). Make sure the link pipes or mufflers are not touching the frame and other parts.



4.







F 49

13. Assemble the seat cowling in the reverse order from the order in which it was removed (F 50, 51, 52, 53).



F 50





F 53

14. Position of the correctly installed Akrapovic SLIP-ON system (F 54).



F 54



## FINAL INSTALLATION AND MAINTENANCE:

Clean grease spots off all exhaust system surfaces, when installation is finished. Cleaning will prevent spots from burning onto the surface. Do not use aggressive chemical cleaners, because they can damage the surface or sticker.

1. Muffler – titanium outer sleeve: use a soft cloth sprayed with a multi-purpose spray lubricant (WD-40® or equivalent)\*.
2. Muffler – carbon-fiber outer sleeve: use a soft dry cloth sprayed with all purpose foam cleaner, then wipe with a soft dry cloth.
3. Muffler – carbon-fiber outlet cap: use a soft dry cloth sprayed with all purpose foam cleaner, then wipe with a soft dry cloth.
4. Painted mufflers and parts – use a soft cloth sprayed with all purpose foam cleaner, then wipe with a soft dry cloth.
5. Chrome plated mufflers and parts: use a soft cloth sprayed with all purpose foam cleaner, then wipe with a soft dry cloth.
6. Stainless steel pipes: use a soft cloth sprayed with a contact cleaner, then wipe with a soft dry cloth.
7. Titanium pipes: use a soft cloth sprayed with a multi-purpose spray lubricant (WD-40® or equivalent)\*.

\*WD-40® is a trademark of the WD-40 Company.

**Periodically make sure all the bolts and springs are sufficiently tight.**



**IMPORTANT: make sure all the bolts are sufficiently tightened. In case the exhaust system touches the cowling or other parts repeat the adjustment of the exhaust system or contact your authorized dealer!**



**CAUTION: after running engine for 30 minutes, retighten the bolts of the Akrapovič carbon-fiber heat shield!**



**INSTALLATION TIP: IT IS NORMAL IF WHITE SMOKE COMES OUT OF THE MUFFLER DURING THE FIRST 100 KM AFTER REPLACEMENT.**



**INSTALLATION TIP: A CHANGE IN THE COLOR OF THE EXHAUST SYSTEM IS NORMAL DUE TO THE HIGH TEMPERATURES.**



**CAUTION: DO NOT STAND BEHIND THE MUFFLER AT ANY TIME.**



**IMPORTANT: DO NOT USE AUTOMOTIVE WHEEL CLEANERS OR ANY CLEANING PRODUCTS WHICH CONTAIN ACIDIC ADDITIVES TO CLEAN AKRAPOVIČ EXHAUST SYSTEMS.**

## TROUBLESHOOTING:

Problem	Possible cause	Solution
Exhaust gas leaks out of the muffler/pipe clamp connections	loosened clamp	tighten the clamp to specified torque
	connection is not completely joined	tap the connection into place and tighten the clamp to specified torque

No.	SalesCode	Description	Qty.
1	S-Y10SO10-HZT	slip on system	1
2	L-Y10SO9L	link pipe TI	1
3	M-HZ03205TL/2	muffler TI	1
4	M-HZ03205T/2	muffler TI	1
5	V-EC106	end cap CA	1
6	V-EC107	end cap CA	1
7	L-Y10SO10L	link pipe Ti	1
8	P-TT18	belt TI for TI sleeve	2
9	P-HSY10R5R	heat shield CA	1
10	P-HSY10R5L	heat shield CA	1
11	V-TUV096	insert SS	1
12	V-TUV096L	insert SS	1
13	P-MCTZ19	muffler clamp CA	1
14	P-DR71	distance ring AL	2
15	P-FB45	bolt	4
16	P-DR4	washer SS	2
17	P-DR47	washer SS	2
18	P-R21	clamp SS	2
19	P-R42	clamp SS	1
20	P-FN2	nut	6
21	P-VST2AL	sticker	2
22	P-DRH1/BAR316	heat resistant washer	4
23	P-DRH4/BAR316	heat resistant washer	4
24	P-FB44	bolt	6
25	P-HF33	ceramic paste	1
26	P-HF661	lambda plug	1
27	P-HF345	lambda fitting kit M18 to M10	1
28	P-FB28	bolt	2
29	P-GUV004	rubber insert	2
30	P-RPCK37	muffler repack kit	1
31	P-RKS225ZT32	muffler sleeve kit	1