



## HOW TO MEASURE

- A** Knee:  
Using a caliper, measure the width of the knee joint across the kneecap. The leg should be completely straight and in a weight-bearing position.

PRODUCT SIZE	BODY MEASUREMENT
INTL SIZE	<b>A</b> KNEE (CM)
S/M/L	9.8 - 11.2
XL/2XL	11.2 - 12.6
INTL SIZE	KNEE (INCHES)
S/M/L	3.86 - 4.41
XL/2XL	4.41 - 4.96