

FILTER CLEANING INSTRUCTIONS



Recommended Service Intervals:

Inspection @ 5000 miles.

Clean @ 10,000 miles.

Filter service intervals will vary depending on riding environment.

Visually inspect and clean as needed.

Cleaning Instructions:

1. Tap the filter element to dislodge loose debris and brush remaining loose debris from filter.
2. Clean filter using water and a mild degreaser like Simple Green or Formula 409.
3. Do not use gasoline, brake cleaner or other harsh chemicals to clean the filter media. These products will erode the filter media. Always inspect filter media and gasket seal for deterioration. Replace filter as needed.
4. Shake off excess water and allow filter to thoroughly dry prior to riding. Do not use compressed air to dry.

NOTE: Do not oil the filter media.

P/N 9925842 Rev 01 06/14

Check out the collection of motorcycle air intake & filters we offer.