


### To Remove Lenses

Grab the top & bottom of the lens with one hand and the frame with the other hand. Pull lens away from the frame until the 2 tabs release from the frame.

### To Replace Lenses

Insert the 2 tabs on either side of the lens bezel into the frame holes. Lenses should fit securely onto frame.



### To Insert/remove Temples

1. Push firmly onto circular button on side of temple.
2. At the same time slip the temple away from the frame.