

TAIL TRUNK INSTALLATION & HINTS

Adjusting Bungee Length:

1. Place Tail Trunk in the desired position on the motorcycle.
2. Place the plastic bungee hooks in the approximate position on the bungee cords to affix them to the appropriate mounting points on your particular motorcycle.
3. Loosen the cord through the holes in the hook, (fig. 1) and then shorten the length from the Tail Trunk to the hook, so that the bungee will have to be stretched a bit to hook to the mounting point on the motorcycle. It is that tension that will decide how firmly the Tail Trunk is mounted to the motorcycle.
4. When all four points are mounted in a basic position, cinch (fig. 2) the bungee cord on the two points on one side; then tighten and cinch the other side. You may have to continue to adjust the tension again on the first side until it meets your satisfaction.



fig. 1



fig. 2

Helpful Hints:

1. If your bungee cords become worn or frayed, they are easily replaced. Untie or cut the old cords and re-route the new bungees through the mounting webbing by looping through twice and pulling them snugly. Adjust to firmly mount tail trunk on seat or rack.
2. Tail Trunks also work as a great coolers. Just line it with a plastic trash bag, fill the bottom with ice and off you go!

Cleaning:

Open all zippers, remove any inserts and hardware, set washer on light or normal cycle, use cold or warm water and a mild detergent. Hang dry. **DO NOT dry clean or put in dryer.** Touch up cleaning may be done with spray cleaners or detergent and water.