

This Honda DOHC CB750 Manual is 336 pages.

QUICK REFERENCE DATA

CHAPTER ONE / GENERAL INFORMATION

Manual organization / Service hints / Safety first / Expendable supplies / Shop tools / Emergency tool kits / Troubleshooting and tune-up equipment

CHAPTER TWO / TROUBLESHOOTING

Starting difficulties / Poor performance / Drive train / Chassis / Brakes / Electrical system / Charging system / Lighting / Fuses / Wiring

CHAPTER THREE / LUBRICATION, MAINTENANCE, AND TUNE-UP

Routine checks / Service intervals / Tires / Crankcase breather hose (U.S. models only) / Battery / Periodic lubrication / Engine oil and filter change / Fork oil change / Drive chain lubrication / Periodic maintenance / Drive chain adjustment / Clutch adjustment / Throttle adjustment / Air filter change / Tune-up / Cylinder head nuts / Camshaft chain adjustment / Valve clearance adjustment / Compression test / Spark plugs / Ignition timing / Carburetor synchronization / Idle speed adjustment / Storage / General specifications

CHAPTER FOUR / ENGINE

Engine principles / Servicing engine in frame / Engine / Cylinder head / Valve and valve components / Camshafts / Camshaft chain / Cylinder block / Pistons and connecting rods / Piston rings / Ignition advance mechanism / Alternator / Oil pump / Oil strainer, oil path body and pressure relief valve / Primary shaft / Primary shaft tensioner / Crankcase / Crankshaft / Electric starter gears / Break-in

CHAPTER FIVE / CLUTCH AND TRANSMISSION

Clutch / Clutch cable / Drive sprocket / Shifting mechanism / Transmission / Gearshift drum and forks

CHAPTER SIX / FUEL AND EXHAUST SYSTEMS

Air cleaner / Carburetors / Carburetor adjustments / Fuel shutoff valve / Fuel tank / Crankcase breather system (U.S.) / Exhaust system

CHAPTER SEVEN / ELECTRICAL SYSTEM

Charging system / Battery / Alternator / Voltage regulator/rectifier / Ignition system / Ignition coil / Pulse generator / Ignition advance mechanism / Spark plugs / Starting system / Starter / Lighting system / Switches / Electrical components / Fuses

CHAPTER EIGHT / FRONT SUSPENSION AND STEERING

Front wheel / Front hub / Wheels / Tire changing / Tire repairs (tube-type tires) / Tire repairs (tubeless tires) / Handlebar / Steering head / Front forks

CHAPTER NINE / REAR SUSPENSION

Wheel / Rear hub / Driven flange assembly / Drive chain / Wheel balancing / Tire changing / Rear swing arm / Shock absorbers

CHAPTER TEN / BRAKES

Front disc brake(s) / Front master cylinder / Front brake pad replacement / Front caliper(s) / Front brake hose replacement / Rear drum brake / Rear master cylinder / Rear brake pad replacement /

Rear caliper / Rear brake hose replacement / Brake disc (front and rear) / Bleeding the system

CHAPTER ELEVEN / FRAME

Kickstand (sidestand) / Centerstand / Footpegs / Frame

SUPPLEMENT / 1981-1982 SERVICE INFORMATION

INDEX

COLOR WIRING DIAGRAMS

Clymer Manuals Honda CB750 DOHC Manual

Clymer Manuals Honda CB750C DOHC Manual

Clymer Manuals Honda CB750K DOHC Manual

Clymer Manuals Honda CB750F DOHC Manual

Clymer Manuals Honda CB750K-LTD DOHC Manual

CB750 dual overhead cam engine models CB 750