

This Honda Motorcycle Manual is 536 pages.

QUICK REFERENCE DATA

CHAPTER ONE / GENERAL INFORMATION

Manual organization / Warnings, cautions and notes / Safety / Serial numbers / Fasteners / Shop supplies / Basic tools / Precision measuring tools / Electrical system fundamentals / Special tools / Basic service methods / Storage / Specifications

CHAPTER TWO / TROUBLESHOOTING

Manual organization / Starting the engine / Starting difficulties / Engine performance / Engine noises / Engine lubrication / Cylinder leakdown test / Clutch / Gearshift linkage / Transmission / Electrical troubleshooting / Test equipment / Basic test procedures / Electrical problems / Charging system / Ignition system troubleshooting / Starter system troubleshooting / Carburetor troubleshooting / Front suspension and steering / Brake problems / Specifications

CHAPTER THREE / LUBRICATION, MAINTENANCE AND TUNE-UP

Fuel / Maintenance schedule intervals / Engine oil and filter change / Tune-up / Air filter / Engine compression test / Spark plugs / Ignition timing / Valve clearance / Carburetor adjustment / Fuel hose inspection / Control cable / Throttle cable operation and adjustment / Choke and clutch cable / Engine oil and filter / Front fork oil change / Drive chain / Brakes / Headlight aim / Sidestand and ignition cutoff switch / Steering bearings / Specifications

CHAPTER FOUR / ENGINE

Removal installation / Cylinder head cover / Camshafts / Cam chain tensioner / Cam chain, timing sprocket and chain guides / Cylinder head / Valves and valve components / Oil pan, oil strainer and pressure relief valve / Oil pump / Oil cooler / Stator coil and left crankcase cover / Flywheel, starter clutch and starter idle gear / Crankcase / Piston and connecting rod assembly / Crankshaft / Break-in procedure / Specifications

CHAPTER FIVE / CLUTCH

Right crankcase cover / Clutch release mechanism / Clutch / Clutch cable replacement / Specifications

CHAPTER SIX / SHIFT MECHANISM AND TRANSMISSION

External shift mechanism / Internal shift mechanism / Transmission troubleshooting / Transmission overhaul / Transmission inspection / Transmission shifting check / Specifications

CHAPTER SEVEN / FUEL AND EMISSION CONTROL SYSTEM

Air filter housing / Carburetor operation / Carburetor service / Carburetor assembly / Carburetor overhaul / Carburetor separation / Float level / Idle drop adjustment / Throttle cable replacement / Choke cable replacement / Fuel tank / Fuel valve / Drain the fuel tank / Fuel pump and fuel filter / Emission control system decals / Crankcase breather system / Evaporative emission control system / Secondary air supply system / Specifications

CHAPTER EIGHT / ELECTRICAL SYSTEM

Battery / Charging system / Alternator / Ignition system / Electric starting system / Starter relay / Clutch diode / Lighting system / Combination meter / Tachometer inspection / Speedometer/speed sensor / Coolant temperature gauge and sensor / Headlight relays / Turn signal relay / Fuel cut relay / Throttle sensor / Horn / Switches / Fuses / Specifications

CHAPTER NINE / LIQUID COOLING SYSTEM

Hoses and hose clamps / Cooling system inspection / Coolant reservoir / Radiator / Cooling fan / Thermostat / Water pump / Specifications

CHAPTER TEN / WHEELS, TIRES AND DRIVE CHAIN

Front wheel / Rear wheel / Wheel runout and balance / Front and rear hubs / Driven flange / Sprocket replacement / Drive chain / Specifications

CHAPTER ELEVEN / FRONT SUSPENSION AND STEERING

Handlebar / Front fork / Steering head and stem / Steering bearing preload check / Steering head bearing races / Specifications

CHAPTER TWELVE / REAR SUSPENSION

Shock absorber / Suspension linkage / Swing arm / Specifications

CHAPTER THIRTEEN / BRAKES

Brake fluid selection / Disc brake / Front brake pads / Front brake caliper / Front master cylinder / Rear caliper / Rear master cylinder / Brake hose replacement / Brake disc / Rear brake pedal / Brake fluid draining / Brake bleeding / Specifications

CHAPTER FOURTEEN / BODY PANELS AND EXHAUST SYSTEM

Seat / Pillion seat / Rear side covers / Rear cowl / Middle fairings / Lower fairings / Upper fairing inner covers / Upper fairing / Windshield / Front fender / Rear fender / Seat rail / Exhaust system / Specifications

INDEX

COLOR WIRING DIAGRAM

Models covered:

1993 1994 1995 1996 1997 1998 1999 Honda CBR900RR

1993 1994 1995 1996 1997 1998 1999 Honda Fireblade (U.K.)

Clymer Manuals Honda Fireblade Manual

Clymer Manuals Honda CBR900RR Manual