

This Kawasaki Motorcycle Manual is 352 pages.

QUICK REFERENCE DATA

CHAPTER ONE / GENERAL INFORMATION

Manual organization / Service hints / Safety first / Expendable supplies / Shop tools / Emergency tool kit / Troubleshooting and Tune-up equipment / Specifications

CHAPTER TWO / TROUBLESHOOTING

Starting difficulties / Poor performance / Drive train / Chassis / Brakes / Electrical system / Charging system / Lighting / Fuses / Wiring

CHAPTER THREE / LUBRICATION, MAINTENANCE AND TUNE-UP

Maintenance schedule / Battery / Engine oil and filter change / General lubrication / Throttle cable lubrication / Drive chain lubrication / Clutch adjustment / Drive chain / Front fork oil level check and fluid change / ear shock absorbers / Tires / Wheels / Wheel bearing lubrication / Brakes / Tune-up / Air filter / Fuel system / Spark plugs / Air suction valves / Valve clearance / Cylinder compression / Carburetor / Throttle play adjustment / Idle speed / Idle mixture / Carburetor synchronization / Storage / Model identification / Specifications

CHAPTER FOUR / ENGINE

Tools / Engine design / Break-in / Servicing engine in frame / Cam chain and tensioner / Ball lock chain tensioner / Cross wedge chain tensioner / Valve cover / Camshafts / Cylinder head / Valves and guides / Cylinder block / Pistons and rings / Engine removal/installation / Oil filter bypass valve / Oil pump / Secondary shaft and starter clutch / Crankcase / Crankshaft and connecting rods / Specifications

CHAPTER FIVE / CLUTCH

Operation / Clutch release / Clutch / Specifications

CHAPTER SIX / TRANSMISSION

Sprocket cover / Engine sprocket / Neutral switch / Shift linkage / Shift detent / Transmission / Shift drum and forks / Transmission gears / Specifications

CHAPTER SEVEN / FUEL AND EXHAUST SYSTEMS

Carburetor operation / Carburetor troubleshooting / Rejetting / Carburetor service / Fuel level inspection / Fast idle adjustment / Crankcase breather / Air suction system / Fuel tank / Fuel tap / Fuel level sending unit / Exhaust system / Specifications

CHAPTER EIGHT / ELECTRICAL SYSTEM

Fuses / Battery / Ignition system / Spark plugs / Ignition advance / Ignition coil / Ignition pickup coils / IC igniter / Charging system / Alternator / Starting system / Starter clutch / Starter solenoid / Lighting system / Turn signal cancelling system / Fuel level sensor / Horn / Voltmeter / Specifications

CHAPTER NINE / WHEELS, TIRES AND BRAKES

Wheels / Front wheels / Speedometer gear lubrication / Rear wheel / Rear sprocket / Wheel bearings and seals / Axle / Tires / Brakes / Brake system bleeding / Brake fluid change / Brake line replacement / Brake pads / Brake calipers / Master cylinder rebuilding / Front master cylinder / Rear master cylinder / Brake discs / Specifications

CHAPTER TEN / CHASSIS

Front fork / Steering / Rear shock absorbers / Swing arm / Drive chain / Specifications

INDEX

WIRING DIAGRAMS

Models covered:

1980 1981 1982 1983 1984 1985 KZ750E KZ750 KZ 750 E
1980 1981 1982 1983 1984 1985 KZ750H KZ750 KZ 750 H
1980 1981 1982 1983 1984 1985 KZ750L KZ750 KZ 750 L
1980 1981 1982 1983 1984 1985 KZ750LTD KZ750 KZ 750 LTD
1980 1981 1982 1983 1984 1985 KZ750R KZ750 KZ 750 R
1980 1981 1982 1983 1984 1985 Z750L Z750 Z 750 L
1980 1981 1982 1983 1984 1985 ZX750A ZX750 ZX 750 A
1980 1981 1982 1983 1984 1985 ZX750E ZX750 ZX 750 E

Clymer Manuals Kawasaki KZ750E Manual
Clymer Manuals Kawasaki KZ750H Manual
Clymer Manuals Kawasaki KZ750L Manual
Clymer Manuals Kawasaki KZ750LTD Manual
Clymer Manuals Kawasaki KZ750R Manual
Clymer Manuals Kawasaki Z750L Manual
Clymer Manuals Kawasaki ZX750A Manual
Clymer Manuals Kawasaki ZX750E Manual1985