

This Yamaha motorcycle manual is 392 pages.

QUICK REFERENCE DATA

CHAPTER ONE / GENERAL INFORMATION

Manual organization / Notes, cautions and warnings / Safety first / Service hints / Washing the bike / Torque specifications / Fasteners / Lubricants / Parts replacement / Emission control and battery decals (TX350) / Basic hand tools / Precision measuring tools / Special tools / Mechanics tips / Specifications

CHAPTER TWO / TROUBLESHOOTING

Operating requirements / Troubleshooting instruments / Starting the engine / Starting difficulties / Engine performance / Engine noises / Excessive vibration / Clutch / Transmission / Ignition system / Front suspension and steering / Brakes / Specifications

CHAPTER THREE / LUBRICATION, MAINTENANCE AND TUNE-UP

Periodic lubrication / Engine oil and filter change / Fork oil change / Control cable lubrication / Periodic maintenance / Chain adjustment / Throttle adjustment / Decompression cable / Air filter / Front fork air pressure / Engine tune-up / Valve clearance check and adjustment / Engine compression check / Carburetor adjustment / Spark Plugs / Ignition timing / Carburetor idle speed adjustment / Storage / Specifications

CHAPTER FOUR / ENGINE TOP END

Cylinder head cover / Camshafts / Cylinder head / Cam chain guides / Valves and valve components / Cylinder / Pistons and piston rings / Specifications

CHAPTER FIVE / ENGINE LOWER END

Removal installation / Crankcase and crankshaft / Break-in procedure / Specifications

CHAPTER SIX / CLUTCH, KICKSTARTER AND EXTERNAL SHIFT MECHANISM

Clutch cover / Clutch / Clutch release mechanism / Primary drive gear and balancer driven gear / Cam chain, sprocket and guide / Kickstarter / Oil pump / External shift mechanism / Clutch cable / Specifications

CHAPTER SEVEN / TRANSMISSION AND INTERNAL SHIFT MECHANISM

Transmission operation / Transmission troubleshooting / Transmission overhaul / Internal shift mechanism / Specifications

CHAPTER EIGHT / FUEL, EXHAUST AND EMISSION CONTROL SYSTEMS

Fuel emission control decals / Air filter / Carburetor service / Carburetor adjustment / Fuel tank / Fuel shutoff valve / Exhaust system / Exhaust system repair / Emission control / Specifications

CHAPTER NINE / ELECTRICAL SYSTEM

Electrical troubleshooting / Charging system / Alternator / Voltage regulator rectifier / Voltage regulator / Ignition system / Ignition coil / Spark plug / Lighting system / Switches / Horn / Condenser / Circuit breaker / Wiring diagrams / Specifications

CHAPTER TEN / FRONT SUSPENSION AND STEERING

Front hub / Tires / Handlebar / Steering head / Front fork / Specifications

CHAPTER ELEVEN / REAR SUSPENSION

Rear wheel / Rear hub / Sprockets / Drive chain / Tire changing and tire repairs / Monocross rear suspension / Monocross shock absorber / Monocross linkage / Rear swing arm / Rear suspension bearing replacement / Specifications

CHAPTER TWELVE / BRAKES

Front disc brake / Front brake caliper / Front master cylinder / Front brake hose / Front brake disc / Brake bleeding / Rear drum brake / Specifications

INDEX

WIRING DIAGRAMS

Models covered:

1986 1987 Yamaha TT350 TT 350

1985 1986 1987 1888 1989 1990 1991 1992 1993 1994 1995 1996 1997 1998 1999 2000 Yamaha
XT350 XT 350

Clymer Manuals Yamaha XT350 Manual

Clymer Manuals Yamaha TT350 Manual

XT350 (1985-2000)

TT350 (1986-1987)