

INSTALLATION INSTRUCTIONS

MAVERICK HORN COVER, CHROME

7474

THANK YOU FOR CHOOSING KURYAKYN!

Protect yourself and others from possible injury and property damage or loss. Pay close attention to all instructions, warnings, cautions, and notices regarding the installation, use, and care of this product.

MARNING

THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

A CAUTION

THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN MINOR OR MODERATE POTENTIAL INJURY.

NOTICE

THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN MAY NEGATIVELY AFFECT PRODUCT PERFORMANCE AND FUNCTIONALITY OR DAMAGE THE PRODUCT ITSELF OR THE PRODUCT TO WHICH IT IS BEING ATTACHED.

ENSURE THAT THE FOLLOWING PARTS HAVE BEEN INCLUDED IN THE KIT:

1 Horn Cover

- 1 Hardware Kit, containing:
 - 1 5/16" Internal Tooth Lock Washer
 - 1 5/16 x 1" Socket Head Cap Screw
 - 1 5/16-18 x 2" Barrel Nut
 - 2 10-24 x 0.625" Button Head Cap Screws
 - 1 Bracket

YOU WILL ALSO NEED:

Hex bit socket set, socket set or combination wrench set, in-lbs (Nm) torque wrench

NOTICE

THESE INSTALLATION INSTRUCTIONS CONTAIN IMPORTANT INFORMATION. ENSURE THE END USER RECEIVES THIS COPY AND IS AWARE OF ITS IMPORTANCE FOR FUTURE USE.

STEP 1

Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn off the ignition. Let motorcycle cool. Remove main fuse.

NOTICE

A FACTORY SERVICE MANUAL MAY BE HELPFUL IN PERFORMING THIS INSTALLATION. DO NOT ATTEMPT TO PERFORM THIS INSTALLATION IF YOU ARE NOT CONFIDENT IN YOUR ABILITY TO COMPLETE ALL OF THE STEPS IN THE PROCEDURE; CONSULT A TRAINED TECHNICIAN.

STEP 2 Test the horn. The horn should sound the same with the new Horn Cover installed.

STEP 3 Remove the acorn nut and washer that attaches the stock horn to the rubber mount on the motorcycle. Set hardware aside, it will NOT be reused.

Refer to PIC 2. Remove the flange nut that secures the horn to the stock mount and cover. Pay attention to the position of the wire connections and the bell. This will be installed on the new bracket in the same orientation. Set the flange nut aside, it will be reused. Remove the horn from the stock cover.





INSTALLATION INSTRUCTIONS

MAVERICK HORN COVER, CHROME

7474

-CONTINUED-

STEP 5

Refer to PIC 3 and 4. Locate provided Bracket. Fasten the horn to the bracket using the flange nut that was removed in Step 4. Be sure the wire harness is located between the back of the horn and bracket, and the terminal connect points are pointing down towards the ground.

TORQUE VALUE FOR FLANGE NUT: 80-100 IN-LBS (9-11.3 NM)

STEP 6

Refer to PIC 5. Locate provided Horn Cover and two (2) Button Head Cap Screws. Fasten the horn and bracket assembly to the Horn Cover.



PIC 5

STEP 7

Refer to PIC 6. Locate provided Barrel Nut. Fasten it to the rubber mount stud, from where the existing horn cover was removed from.

TORQUE VALUE FOR BARREL NUT: 35-55 IN-LBS (3.9-6.2 NM)





STEP 8

Refer to PIC 8 and 9. Locate provided internal tooth lock washer and socket head cap screw. Insert the screw through the mounting hole on the front top side of the horn cover. On the inside of the horn cover, thread the lock washer onto the screw.

STEP 9

Refer to PIC 10. Align the horn cover assembly over the barrel nut. Fasten assembly to the barrel nut. Fully tighten hardware.

TORQUE VALUE FOR SOCKET SCREW: 80-120 IN-LBS (9-13.6 NM)





STEP 10 Reinstall main fuse and test the horn.



INSTALLATION INSTRUCTIONS

MAVERICK HORN COVER, CHROME

7474

-CONTINUED-

NOTICE

IT IS THE INSTALLER'S RESPONSIBILITY TO ENSURE THAT ALL OF THE FASTENERS (INCLUDING PRE-ASSEMBLED) ARE TIGHTENED BEFORE OPERATION OF THE MOTORCYCLE. KURYAKYN WILL NOT PROVIDE WARRANTY COVERAGE ON PRODUCTS OR COMPONENTS LOST DUE TO IMPROPER INSTALLATION OR LACK OF MAINTENANCE. PERIODIC INSPECTION AND MAINTENANCE ARE REQUIRED ON ALL FASTENERS.

LIMITED WARRANTY

Kuryakyn warrants that any Kuryakyn products sold hereunder, shall be free of defects in materials & workmanship for a period of one (1) year from the date of purchase by the consumer excepting the following provisions:

- 1. Kuryakyn shall have no obligation in the event the customer is unable to provide a receipt showing the date the customer purchased the product(s).
- 2. The product must be properly installed, maintained & operated under normal conditions.
- 3. Kuryakyn shall not be liable for any consequential & incidental damages, including labor & paint, resulting from failure of a Kuryakyn product, failure to deliver, delay in delivery, delivery in nonconforming condition, or for any breach of contract or duty between Kuryakyn & a customer.
- 4. Kuryakyn products are often intended for use in specific applications. Kuryakyn makes no warranty if a Kuryakyn product is used in applications other than intended.
- 5. Kuryakyn electrical products are warranted for one (1) year from the date of purchase by the consumer. L.E.D.'s contained in components of Kuryakyn products will be warranted for defects in materials & workmanship for 3 years from the date of purchase whereas all other components shall be warranted for one (1) year.
- 6. All warranty claims must be directed to the place of purchase. Merchandise sold through internet auction sites or any other unauthorized reseller shall not carry a Kuryakyn warranty. If unsure, please contact the place of purchase to verify they are an authorized Kuryakyn reseller.