D_R Beasley's Your Detailing Prescription

- 1. When cleaning your engine, it is very important to stay clear of wires, gaskets, and moving parts as these can be potentially hot and/or problematic. The first step is to lightly spray water and Dr. Beasley's Premium Degreaser on all hoodjams and plastic parts (solid surfaces).
- **2.** Once wetted, use the provided Parts Cleaning Brush to remove grease and grime from the engine.
- **3.** Once cleaned, use the Microfiber Applicator to apply the Plastic Sealant to any plastic surfaces within the engine such as hoses, wire casings, or engine covers in order to prevent fading, cracking, and future buildup.
- **4.** Let sealant dry and apply more where needed. Once the sealant has dried, wipe off gently with a Microfiber Towel to reveal your engine's shine.