

Q621.001 2003-2009 Arctic Cat 500l Auto 4X4 Stage 1

For mildly tuned machines using the stock airbox with stock or aftermarket filter. May also be used with a good aftermarket exhaust system.

| Parts List | | |
|------------|-------------------|--------|
| 1 | Main Jet | DJ134 |
| 1 | Main Jet | DJ136 |
| 1 | Main Jet | DJ138 |
| 1 | Main Jet | DJ140 |
| 1 | Main Jet | DJ142 |
| 1 | Main Jet | DJ144 |
| 1 | Main Jet | DJ146 |
| 1 | Main Jet | DJ148 |
| 1 | Main Jet | DJ150 |
| 1 | Fuel Needles | DNO106 |
| 2 | Adjusting Washers | DW0001 |
| 1 | E-Clip | DE0001 |

STAGE ONE INSTRUCTIONS

- 1.Remove vacuum slide from carb. Remove stock needle & spacers, noting order of assembly (Fig.A).
- 2. Install Dynojet needle on groove #3 for applications below 5000 feet, groove #2 for above 5000 feet, using all stock spacers. Install the Dynojet washers above the E-clip (Fig.A).
- 3. Remove stock main jet and replace with Dynojet main jet provided. Use the DJ144 below 3000 feet, DJ140 from 3000 to 6000 feet and DJ136 above 6000 feet. When using an aftermarket exhaust with a high flow baffle, Use the DJ148 below 3000 feet, DJ144 from 3000 to 6000 feet and the DJ140 above 6000 feet. When using an aftermarket exhaust with a quiet baffle, Use the DJ146 below 3000 feet, DJ142 from 3000 to 6000 feet and the DJ138 above 6000 feet.
- 5. Locate the Fuel Mixture Screw (Fig.B). Using a flat blade screwdriver, turn the mixture screw clockwise until it seats, then turn out 3 turns, 2.5 turns above 5000 feet.





