







**Mounting Instructions**  
**Work lamps**



**MegaBeam LED**  
**Module 70 LED**



**TOP**



**Headlamp must not be covered.**

## ***Product liability***

- National mounting, fitting and operating regulations must be heeded and kept.
- Please read all the instructions and safety notes included before using the device.
- We reserve the right to make technical and optical modifications within the course of product improvement.
- Only use original spare parts or spare parts approved by HELLA.
- If you have any questions or installation problems, call HELLA customer services, your wholesaler or contact your specialist garage.

## ***Technical Data***




<b>Nominal voltage</b>	<b>Range of voltage</b>	<b>Input values</b>	<b>Admissible ambient temperature</b>	<b>Class of protection IP 6K 9K</b>
12V	9V – 30V	<700 mA <8,5 W	-40°C up to +50°C	(Protection against splash water and dust)
24V	9V – 30V	<400 mA <10,2 W		
48V	36V – 80V	<200 mA <9,6 W		
80V	36V – 80V	<200 mA <16 W		

Admissible length of cable max. 10 m in accordance with ECE

**Operation of the light using alternating voltage or clocked direct voltage is not permitted!**




Surface-mounted worklamp

**Mega Beam**




Surface-mounted worklamp

Module 70



Electrical connection



460 879-09 02/09



Discover other off-road lights on our website.