


Instruction Sheet For Fork Seal Installer





PARTS AVAILABLE SEPARATELY			
No.Qty.		y. Description	Part No.
1	1	35mm SLIDER	2045
2	1	39mm SLIDER	2046
3	1	41mm SLIDER	2047
4	1	INDESTRUCTABLE DELRIN CAP	2048
5	1	INSTRUCTION SHEET	2044-IS

Refer to H.D.® Service Manual for specifications.

- 1. After thoroughly cleaning and inspecting the fork tubes, sliders, and components, making sure to remove all burrs from the areas where the seal makes contact, coat the fork tube with a film of light grease. Place seal in position, making sure seal lip is facing the right direction. Refer to H.D.® manual or seal manufacturers instructions.
- 2. Place JIMS® Fork Seal installation tool over fork tube. Push seal into place by lightly ramming with the installation tool in a slide hammer motion until seal is seated and the retaining ring can be installed.
- 3. On 39mm model forks the dust seal and chrome top cover can be easily installed without damage by simply using the black Delrin adapter ring #2048 between the slide driver and the part.

FORK SEAL & CAP INSTALLERS

Use to install fork seals, dust seals, and chrome caps. Lightly grease to keep from scratching fork tubes.

No.**2044 -** 39mm slider with Delrin plastic indestructable cap. 2 piece kit.

CAUTION: Wear safety glasses. Excessive force may damage parts! ,See JIMS® catalog for over 100 other top quality professional tools. The last tools you will ever need to buy.