

KICKER®

HARLEY DAVIDSON AUDIO PROGRAMMER

HARLEY DAVIDSON AUDIO PROGRAMMER

INCLUDED COMPONENTS:

- (1) Programmer module
- (1) USB Cable
- (1) Diagnostic Connection Cable
- (1) Download Instructions

NOTE 1: In order to utilize the Kicker Audio Module, the stock ECM **MUST** be used. For motorcycles with:

NOTE 2: *MUST BE CONNECTED TO THE INTERNET*

Stock ECM: Follow the provided instructions with the Audio Module

Power Commander: Disconnect the Power Commander from the ECM circuit. Reconnect the ECM to the stock harness plug and then follow the provided instructions with the Audio Module

Any Aftermarket ECM: Disconnect your aftermarket ECM and install your stock ECM to the bike harness. Follow the provided instructions with the Audio Module. (For some ECMs this will mean reinitializing the aftermarket ECM when it is reinstalled)

INSTALLING THE SOFTWARE FOR A FIRST TIME USER

1. **Download** software program from technoresearch.com.
2. Once the download completes, **Run** software installer
3. **Connect** your Kicker program module to your computer using supplied USB cable
4. From the Icon on your desktop **Start the Centurion software**
5. Allow software to update, accept terms and conditions and select language to launch program

PROGRAMMING LIKE A PRO

1. Remove side cover from left side of bike and locate the bottom 6 pin diagnostic plug
2. Connect your programmer to the bike
3. Turn ignition switch to the Accessory position
4. Launch program
5. To connect to the bike, select the icon with two arrows facing each other
6. Once connected to the bike, select the icon with the Wrench on it
7. You will now see a drop-down menu. From this menu you can read and reset DTC's, and complete programming for adding Kicker Audio upgrade kits.

2 SPEAKER FRONT KIT

If you are installing a 2 speaker/single amp kit complete the following:

1. Select Radio speaker programming
2. Select 2 Speakers- Front Speaker Kit
3. Select Program Speaker
 - a. Follow onscreen directions, complete and look for Pass on the menu
4. Select from the drop-down menu: Radio Front Rear amp
5. Select Front and Start
 - a. Click enable and flash
 - b. Follow the onscreen directions (confirm Pass)
6. Exit the program

4 SPEAKER FRONT AND REAR KIT

If you are installing both front and rear kits complete the following:

1. Select Radio speaker programming
2. Select 4 Speakers- Front and Rear Speaker Kit
3. Select Program Speaker
 - a. Follow onscreen directions, complete and look for Pass on the menu
4. Select from the drop-down menu: Radio Front Rear amp
5. Select Front and Start
 - a. Click enable and flash
 - b. Follow the onscreen directions (confirm Pass)
6. Repeat again for Rear Amp
7. Exit the program