

INSTALLATION INSTRUCTIONS PART NUMBER:BU-9003

Congratulations, you have just purchased the finest air filter that money can buy. With proper care, this filter will last 1 million miles or more. This filter can be used in a stock machine, with no modifications required. If any engine modifications have been made tuning/jetting adjustments may be required. There are special installation instructions, so please follow the procedures outlined below to ensure the K&N[®] air filter seals properly.

INSTALLATION:

- 1. Remove the stock <u>air filter</u>.
- 2. Carefully clean the area where the air filter sits in the air box.
- 3. Install the K&N® air filter. (Fig. 1)
 - NOTE: The air filter will not be completely seated in the air box at this time. The flat surface on the inside of the air box lid will apply pressure on the K&N[®] air filter to complete the seal. (Fig. 2)
- 4. Reinstall the air box lid and refasten clips. (Fig. 3)

THESE INSTRUCTIONS MUST BE FOLLOWED EVERY TIME THE FILTER IS SERVICED, OTHERWISE THE FILTER MAY NOT SEAL, AND DAMAGE TO THE ENGINE COULD RESULT.



Fig. 1



Fig. 2




Fig. 3