


Congratulations, you have purchased the finest <u>air filter</u> that money can buy. With proper care, this filter can last many seasons. This filter can be used in a stock machine, with no modifications required. If any engine modifications have been made tuning/jetting adjustments may be required. There are special installation instructions, so please follow the procedures outlined below to ensure the K&N Filtercharger® seals properly.

INSTALLATION

- 1. Remove the stock air filter.
 - **Note:** The stock air filter cage will not be used with the K&N Filtercharger[®].
- 2. Carefully clean the air filter sealing surface.
- 3. Install the K&N Filtercharger® making sure it is completely seated.
 - **Note:** Notice the direction of the slot on the K&N Filtercharger[®]. (Fig. 1)
- 4. Install the air filter retainer into the slot of the K&N Filtercharger[®]. (Fig. 2)
- 5. Fasten the air filter retainer. (Fig. 3)

THESE INSTRUCTIONS MUST BE FOLLOWED EVERY TIME THE FILTER IS SERVICED, OTHERWISE THE FILTER MAY NOT SEAL, AND DAMAGE TO THE ENGINE COULD RESULT.








Fig. 1 Fig. 2

Fig. 3