

Congratulations, you have purchased the finest <u>air filter</u> that money can buy. With proper care, this filter will last 1 million miles or more. This filter can be used in a stock machine, with no modifications required. If any engine modifications have been made tuning/jetting adjustments may be required. There are special installation instructions, so please follow the procedures outlined below to ensure the K&N air filter seals properly.

INSTALLATION

- 1. Remove the stock air filter.
- 2. Install the K&N Air Filter. The round opening will be facing down into the air box. (Fig. 1)
- 3. Completely seat the K&N Air Filter. The filter will sit flush in the air box. (Fig. 2)
- 4. Reinstall the air box lid.

THESE INSTRUCTIONS MUST BE FOLLOWED EVERY TIME THE FILTER IS SERVICED, OTHERWISE THE FILTER MAY NOT SEAL, AND DAMAGE TO THE ENGINE COULD RESULT.



Fig. 1



Fig. 2