

Congratulations, you have purchased the finest <u>air filter</u> that money can buy. With proper care, this filter can last many seasons. This filter can be used in a stock machine, with no modifications required. If any engine modifications have been made tuning/jetting adjustments may be required. There are special installation instructions, so please follow the procedures outlined below to ensure the K&N Filtercharger® seals properly.

INSTALLATION

- 1. Remove the stock air filter.
- 2. Clean the air filter sealing groove in the air box. (Fig. 1)
- 3. Using the provided K&N Sealing Grease, apply a thick even layer into the air filter sealing groove. (Fig. 1)
- 4. Install the K&N Filtercharger® making sure it is completely seated.

THESE INSTRUCTIONS MUST BE FOLLOWED EVERY TIME THE FILTER IS SERVICED, OTHERWISE THE FILTER MAY NOT SEAL, AND DAMAGE TO THE ENGINE COULD RESULT.




Fig. 1