Congratulations, you have purchased the finest air filter that money can buy. With proper care, this filter will last 1 million miles or more. This filter may be used in a stock machine, with no modifications required. However, if any modifications have been made, tuning/jetting adjustments may be required. The following procedure MUST be followed to ensure a proper fit and seal of the K&N Air Filter.

## **GASKET INSTALLATION**

- 1. Clean the top plate of the K&N Air Filter.
- 2. Remove the backing of the provided gasket.
- 3. Apply the gasket to the top plate of the K&N Air Filter.

Note: The gasket is not used to seal the air filter. It is a cushion for the air cleaner cover.

THESE INSTRUCTIONS MUST BE FOLLOWED EVERY TIME THE FILTER IS SERVICED, OTHERWISE THE FILTER MAY NOT SEAL, AND DAMAGE TO THE ENGINE COULD RESULT.