Congratulations, you have purchased the finest <u>air filter</u> that money can buy. With proper care, this filter will last 1 million miles or more. This filter may be used in a stock machine, with no modifications required. However, if any modifications have been made, tuning/jetting adjustments may be required. The following procedure MUST be followed to ensure a proper fit and seal of the K&N Air Filter.

INSTALLATION

- 1. Remove the stock air filter.
- 2. Clean the base plate where the air filter seals.
- 3. Apply the supplied gasket to the base plate.
- Install the K&N Air Filter.

THESE INSTRUCTIONS MUST BE FOLLOWED EVERY TIME THE FILTER IS SERVICED, OTHERWISE THE FILTER MAY NOT SEAL, AND DAMAGE TO THE ENGINE COULD RESULT.