



INSTALLATION INSTRUCTIONS

PART NUMBER: KT-1108

Congratulations, you have purchased the finest air filter that money can buy. With proper care, this filter can last many seasons. This filter can be used in a stock machine, with no modifications required. If any engine modifications have been made tuning/jetting adjustments may be required. There are special installation instructions, so please follow the procedures outlined below to ensure the K&N® air filter seals properly.

INSTALLATION:

1. Remove the stock [air filter](#).
2. Wipe any dirt that may be present around the sealing area in the air box.
3. Using the supplied K&N® sealing grease, apply a liberal amount of grease around the perimeter of the filter on the underside. (Fig. 1)
4. Install K&N® air filter into air box. Ensure filter seats correctly in air box. (Fig. 2)
5. Re-install air box lid.

THESE INSTRUCTIONS MUST BE FOLLOWED EVERY TIME THE FILTER IS SERVICED, OTHERWISE THE FILTER MAY NOT SEAL, AND DAMAGE TO THE ENGINE COULD RESULT.



Fig. 1



Fig. 2