

Congratulations, you have purchased the finest air filter that money can buy. With proper care, this filter can last many seasons. This filter can be used in a stock machine, with no modifications required. If any engine modifications have been made tuning/jetting adjustments may be required. There are special installation instructions, so please follow the procedures outlined below to ensure the K&N® air filter seals properly.

INSTALLATION:

- 1. Remove the stock air filter.
- 2. Install the K&N[®] air filter into the stock air box base making sure it is completely seated. (Fig. 1)

 NOTE: The air filter will only fit into the air box one way. Do not remove the air filter o-ring in the air box.
- 3. Reinstall the air box lid.
- Reinstall the stock screws into the air box lid and tighten.
 NOTE: Make sure the center screw is installed as this screw holds the air filter in place. (Fig. 2)

THESE INSTRUCTIONS MUST BE FOLLOWED EVERY TIME THE FILTER IS SERVICED, OTHERWISE THE FILTER MAY NOT SEAL, AND DAMAGE TO THE ENGINE COULD RESULT.





Fig. 1 Fig. 2