Congratulations, you have purchased the finest <u>air filter</u> that money can buy. With proper care, this filter will last 1 million miles or more. This filter can be used in a stock machine, with no modifications required. If any engine modifications have been made tuning/jetting adjustments may be required. There are special installation instructions, so please follow the procedures outlined below to ensure the K&N air filter seals properly.

## **INSTALLATION**

- 1. Remove the stock air filter.
- 2. Carefully clean the inside of the air box.
- 3. Remove the stock intake tube from the air box lid.
  - **Note:** The intake tube will not be used with the K&N Filtercharger.
- 4. Install the K&N Filtercharger making sure it is completely seated.
  - **Note:** The stock air filter hold down will not be used with the K&N Filtercharger.
- 5. Reinstall the air box lid.

THESE INSTRUCTIONS MUST BE FOLLOWED EVERY TIME THE FILTER IS SERVICED, OTHERWISE THE FILTER MAY NOT SEAL, AND DAMAGE TO THE ENGINE COULD RESULT.