



INSTALLATION INSTRUCTIONS

Part Number SU-4000

Congratulations, you have purchased the finest [air filter](#) that money can buy. With proper care, this filter can last many seasons. This filter can be used in a stock machine, with no modifications required. If any engine modifications have been made tuning/jetting adjustments may be required. There are special installation instructions, so please follow the procedures outlined below to ensure the K&N Filtercharger® seals properly.

INSTALLATION

1. Remove the stock air filter and air filter holder.
Note: The stock air filter holder will not be used with the K&N Filtercharger®.
2. Carefully clean the air filter sealing surface in the air box.
3. Apply the provided K&N Sealing Grease to the air filter sealing surface in the air box.
4. Install the K&N Filtercharger® making sure the hold down rod is seated in the groove properly.
5. Reinstall the air box side panel.

Available to purchase separately

Precharger Wrap; SU-4000PK

THESE INSTRUCTIONS MUST BE FOLLOWED EVERY TIME THE FILTER IS SERVICED, OTHERWISE THE FILTER MAY NOT SEAL, AND DAMAGE TO THE ENGINE COULD RESULT.
