Congratulations, you have purchased the finest <u>air filter</u> that money can buy. With proper care, this filter will last 1 million miles or more. This filter is a direct replacement for the stock air filter, and no modification will be required. However the following procedures MUST be followed to ensure the proper fit and seal of the K&N® air filter.

## **INSTALLATION:**

- 1. Remove the stock air filter.
- 2. Carefully clean the sealing perimeter in the air box.
- 3. Apply a layer of the provided K&N<sup>®</sup> Sealing Grease around the perimeter of the air filter in the seal groove.
- 4. Install the K&N® Air Filter in the air box base.
- 5. Re-install the air box cover.

THESE INSTRUCTIONS MUST BE FOLLOWED EVERY TIME THE FILTER IS SERVICED, OTHERWISE THE FILTER MAY NOT SEAL, AND DAMAGE TO THE ENGINE COULD RESULT.