



INSTALLATION INSTRUCTIONS

PART NUMBER: SU-6596

Congratulations, you have purchased the finest [air filter](#) that money can buy. With proper care, this filter can last many seasons. This filter can be used in a stock machine, with no modifications required. If any engine modifications have been made tuning/jetting adjustments may be required. There are special installation instructions, so please follow the procedures outlined below to ensure the K&N® air filter seals properly.

INSTALLATION:

1. Remove the stock air filter according to the service manual.
2. Wipe away any dust and debris from the inside of the airbox and all sealing surfaces.
3. Apply the provided gasket to the inside of the airbox. (Fig. 1 and Fig. 2)
4. Install the K&N® air filter into the airbox. (Fig. 3) Insert the provided lever clamp as shown. (Fig. 4)

NOTE: The flared piece sits behind the bump on the air filter.

5. Tighten the stock screw. (Fig. 4)

THESE INSTRUCTIONS MUST BE FOLLOWED EVERY TIME THE FILTER IS SERVICED, OTHERWISE THE FILTER MAY NOT SEAL, AND DAMAGE TO THE ENGINE COULD RESULT.



Fig. 1




Fig. 2




Fig. 3



Fig. 4