



INSTALLATION INSTRUCTIONS

PART NUMBER: SU-7506

Congratulations, you have purchased the finest air filter that money can buy. With proper care, this filter can last many seasons. This filter can be used in a stock machine, with no modifications required. If any engine modifications have been made tuning/jetting adjustments may be required. There are special installation instructions, so please follow the procedures outlined below to ensure the K&N® air filter seals properly.

INSTALLATION:

1. Remove the stock [air filter](#).
2. Remove the stock o-ring where the air filter seals. (Fig. 1)
NOTE: Do not remove the o-ring for the air box lid otherwise the air box will not seal correctly. (Fig. 2)
3. Install the K&N® air filter. (Fig. 3)
4. Go around the perimeter of the K&N® air filter and make sure it is completely seated in the o-ring groove.
5. Reinstall the air box lid and tighten the stock screws.

THESE INSTRUCTIONS MUST BE FOLLOWED EVERY TIME THE FILTER IS SERVICED, OTHERWISE THE FILTER MAY NOT SEAL, AND DAMAGE TO THE ENGINE COULD RESULT.



Fig. 1



Fig. 2



Fig. 3