



# Installation Instructions

## Part Number: SU-8005

Congratulations, you have just purchased the finest air filter that money can buy. With proper care, this filter will last 1 million miles or more. This filter can be used in a stock machine, with no modifications required. If any engine modifications have been made tuning/jetting adjustments may be required. There are special installation instructions, so please follow the procedures outlined below to ensure the K&N air filter seals properly.

### INSTALLATION:

1. Remove the stock air filter.
2. Remove the stock gasket from around the stock air filter and install on the K&N [Air Filter](#). (Fig. 1)
3. Remove grommet from stock filter and install on the K&N. (Fig. 2)
4. Remove the stock inlet tube and install it into the K&N Air Filter. (Fig. 3)  
**Note: On the back of the K&N Air Filter there are two locator bumps to line up the inlet tube. (Fig. 4)**
5. Install the K&N Air Filter into the air box making sure it is completely seated.
6. Reinstall the air box cover and tighten the screws.

**THESE INSTRUCTIONS MUST BE FOLLOWED EVERY TIME THE FILTER IS SERVICED, OTHERWISE THE FILTER MAY NOT SEAL, AND DAMAGE TO THE ENGINE COULD RESULT.**



Fig. 1



Fig. 2




Fig. 3



Fig. 4