

INSTALLATION INSTRUCTIONS PART NUMBER: YA-2002

Congratulations, you have purchased the finest <u>air filter</u> that money can buy. With proper care, this filter can last many seasons. This filter can be used in a stock machine, with no modifications required. If any engine modifications have been made tuning/jetting adjustments may be required. There are special installation instructions, so please follow the procedures outlined below to ensure the K&N® air filter seals properly.

INSTALLATION:

- 1. Remove the stock air filter.
- 2. Clean all sealing surfaces in the air box including any necessary areas inside the air-boot ensuring you start as clean as possible.
- 3. Apply supplied grease around the perimeter of the channel on the bottom of the air filter as shown (opposite side of engravings). (Fig.1).
- 4. Place air filter in air box base. (Fig. 2)
- 5. Place air box lid back on air box base and fasten tight.

Note: The plastic cage in the top will still be used in the installation of the K&N air filter. (Fig. 3)

THESE INSTRUCTIONS MUST BE FOLLOWED EVERY TIME THE FILTER IS SERVICED, OTHERWISE THE FILTER MAY NOT SEAL, AND DAMAGE TO THE ENGINE COULD RESULT.





Fig. 1 Fig. 2



Fig. 3