



INSTALLATION INSTRUCTIONS

PART NUMBER: YA-6008

Congratulations, you have purchased the finest air filter that money can buy. With proper care, this filter can last many seasons. This filter can be used in a stock machine, with no modifications required. If any engine modifications have been made tuning/jetting adjustments may be required. There are special installation instructions, so please follow the procedures outlined below to ensure the K&N® air filter seals properly.

INSTALLATION:

1. Remove the stock [air filter](#).
2. Install the K&N® air filter into the stock air box. Make note of the three clips on the air filter in Fig. 1a. These clips will slide into place as the air filter is slide down into the air filter cavity in the air box. (Fig. 1b)
NOTE: The K&N® air filter will only fit into the air box one way. Do not remove the air filter o-ring in the air box.
3. Apply pressure to the air filter as shown in Fig. 2 so the air filter snaps into place and completely seals into the air box.
4. If properly installed the air filter will seal into the air box as shown.(Fig. 3) Reinstall the stock screws that secure the air filter to the air box.
5. Reinstall the air box lid and reinstall the stock screw that secures the air box lid.

NOTE: Make sure to install the center screw on the air box lid as this screw holds the air box lid and air filter in place. (Fig. 4)

THESE INSTRUCTIONS MUST BE FOLLOWED EVERY TIME THE FILTER IS SERVICED, OTHERWISE THE FILTER MAY NOT SEAL, AND DAMAGE TO THE ENGINE COULD RESULT.



Fig.1a




Fig.1b



Fig. 2



Fig. 3



Fig. 4