



# INSTALLATION INSTRUCTIONS

## PART NUMBER: AL-1010

This filter fits: SEE CATALOG FOR CURRENT APPLICATIONS

Congratulations, you have purchased the finest air filter that money can buy. With proper care, this filter will last 1 million miles or more. This filter can be used in a stock machine, with no modifications required. If any engine modifications have been made tuning/jetting adjustments may be required. There are special installation instructions, so please follow the procedures outlined below to ensure the K&N® air filter seals properly.

### INSTALLATION:

1. Remove the three screws and dirty air filter. Fig. 1
2. Detach the filter support tray by removing the two screws. Fig. 2 & 3  
**NOTE: Support tray will not be needed when installing the K&N® filter.**
3. Install K&N® Air Filter in the air box base, using the original screws. Fig. 4
4. Reinstall the air box lid.

**THESE INSTRUCTIONS MUST BE FOLLOWED EVERY TIME THE FILTER IS SERVICED, OTHERWISE THE FILTER MAY NOT SEAL, AND DAMAGE TO THE ENGINE COULD RESULT.**




Fig. 1



Fig. 2



Fig. 3




Fig. 4

### CLEANING:

K&N Engineering, Inc., suggests checking the air filter element periodically for excessive dirt build-up. Depending on your driving conditions, we recommend cleaning your air filter every 50,000 miles. To clean and re-oil, purchase our filter Recharger® service kit, part number 99-5050 or 99-5000 and follow the easy instructions.